# Importing La Crosse LIDAR data into AutoCAD

The Light Detection and Ranging (LiDAR) LAS dataset for LaCrosse County is a topographic survey consisting of 654 tiles. Each tile is 5,000 Feet X 5,000 Feet. To give you an idea of how dense the data is, the tile used in our example has over 623,000 elevation points! If we placed the entire tile into AutoCAD our DWG file would be over 20MB! To reduce the file size, and not bog down Cad, we can clip a portion of the tile (our project area) and import only that area into AutoCAD.




*This is the 5,000' x 5,000' tile; each black dot is a Lidar point!* 

- Open ArcMap or Toolkit
  - Make sure to add the following data layer, if it is not already loaded:
    - C:\lacrosse\_lidar\_2007\LaCrosse\_Tiles\_STP.shp
  - Optional data layers include:
    - If you want to see the 2' contours in ArcMap: C:\lacrosse\_lidar\_2007\05\_Contours\LaCrosse\_County\_Contours.gdb\Contours
    - The LaCrosse Ortho Photo (Hi-Def) can also be added: C:\ortho\_imagery\ortho\_wi063\_2007\_12in\_color\_spcs.sid
- Zoom into the area of interest.
- Turn on the "LaCrosse\_Tiles\_STP" layer to find which XYZ tile you will be using (you may have to turn on the labels, or you can use the information tool).



For this example our project is highlighted in the red circle, and is located in Tile #1540.

- Navigate to C:\geodata\lacrosse\_lidar\_2007\02\_Bare\_Earth\_XYZ folder.
- Open the appropriate XYZ file in Notepad (*for this example: Tile1540.xyz*)
- Save the file as a Text Document (*Be sure to leave the .TXT in the file name*)



- Open the TXT file.
- Insert a return before the first line and type in the following: Easting, Northing, Elevation
- The file will look like this:

u	ns.				
	D 1	ile1:	i40.txt	- Note	epad
	File	Edit	Format	View	Help
	168 168 168 168 168 168 168 168 168 168	0241 0242 0243 0230 0231 0234 0236 0237 0239 0240 0242 0243 0243 0241 0239	.0700, .5100, .9500, .9500, .4000, .8500, .2800, .7200, .1600, .5800, .0200, .4400, .2000, .4400, .2000, .7400,	6849 6849 6849 6849 6849 6849 6849 6849	<pre>g, Elevation 775.1600,840.8700 966.9800,840.4500 966.9800,840.6000 996.2600,836.9700 988.3600,838.8500 980.4600,840.4700 972.5100,842.0000 964.5600,842.8000 956.5200,843.6000 932.4600,844.3500 932.4600,844.3500 932.4600,844.900 932.4600,844.900 932.4600,844.1000 929.7900,844.1100 937.8800.843.8700</pre>
	100	0776	0100	C040	ME 0100 045 E500

• Save your changes and exit Notepad/Wordpad.

- Open ArcCatalog and navigate to where the TXT file was saved.
- Select the TXT file, right-click and select "Create Feature Class > From XY Table".

Name		Туре
🗐 Tile1540.t:		Text File
	Copy Ctrl+C	
	X <u>D</u> elete	
	Rena <u>m</u> e F2	
	Export 🕨	
	Create <u>F</u> eature Class 🕨	From <u>X</u> Y Table
	Properties	

This will create a shapefile from the XYZ text file (creating a point for every single LIDAR point).

• Match up the X, Y, and Z field to the Easting, Northing, and Elevation fields you typed into the TXT file. It should look like this when you have them matched:

Input Fields		
× Field:		
Easting	•	
Y Field:		
Northing	•	
Z Field:		
Elevation	<b>•</b>	Click on the "Coordinate System of Input
Coordinate Sys	stem of Input Coordinates	<i>Coordinates</i> " button to specify what coordinates the
Output		Lidar data is in.
	hapefile or feature class:	
C:\temp\XYTile	1540.shp 🖻	Spatial Reference Properties
Conferences		XY Coordinate System Z Coordinate System
Configuration ke	ywora.	Name: Unknown
1	<u> </u>	, Details:
Advanced Ge	eometry Options	
	OK Cancel	
		v
	Click the "Select"	button Select a predefined coordinate system.
		Import a coordinate system and X/Y, Z and M Import domains from an existing geodataset (e.g.,
	L	feature dataset, feature class, raster).
		New  Create a new coordinate system.
		Edit the properties of the currently selected
		Modify Ear the properties of the currently selected coordinate system.
		coordinate system.

	Browse for Coordinate System
then navigate to:	Look in: 🗀 NAD 1983 (Feet) 🔽 💁 🎬 🧱 🏭
Projected Coordinate Systems > State Plane > NAD83 (feet) > NAD 1983 State Plane Wisconsin South FIPS 4803 (feet).prj	tir MAD 1983 StatePlane Wisconsin Central FIP5 4802 (Feet).prj HAD 1983 StatePlane Wisconsin North FIP5 4801 (Feet).prj MAD 1983 StatePlane Wisconsin South FIP5 4803 (Feet).prj NAD 1983 StatePlane Wyoming East Central FIP5 4902 (Feet).prj NAD 1983 StatePlane Wyoming Cast FIP5 4901 (Feet).prj NAD 1983 StatePlane Wyoming West Central FIP5 4903 (Feet).prj NAD 1983 StatePlane Wyoming West FIP5 4904 (Feet).prj NAD 1983 StatePlane Wyoming West FIP5 4904 (Feet).prj er
Click the "Add" button to set the	Name: NAD 1983 StatePlane Wisconsin South FIPS 4803 (Feet).p Add
coordinate system.	> Show of type: Coordinate Systems Cancel
and	
"OK" on the Spatial Reference	

Create Feature Class From XY Table 🛛 🛛 🔀
Input Fields
× Field:
Easting
Y Field:
Northing
Z Field:
Elevation 💌
Coordinate System of Input Coordinates
Output
Specify output shapefile or feature class:
C:\temp\XYTile1540.shp
Configuration keyword:
· ·
Advanced Geometry Options
OK Cancel


Properties window.

be created by clicking on the Browse Folder icon. Once you have given the filename and path, click on the

Choose the location and the filename for the shapefile to

OK button to create the shapefile.

- Add the new shapefile into your ArcMap session.
- Using the *Select Features* button, draw a box around the desired area (your project area).




This selection has ~45,000 points, which is about 7% of the points in the tile!!!


#### Now we will create a text file to be used in AutoCAD!

#### **Text File Creation**

• With the XYZ shapefile selected in the Data Frame, and your project area points selected, right-click and select "Open Attribute Table".



- At the bottom of the Attribute Table be sure to select "Show—Selected"
- Select the "Options" button in the lower right, and then select "Export".



• Select "Text File" in the "Save as Type" box. Choose the file path and type in a file name. Click the "Save" button when you are done.


\*\*\* Be sure to save this file in a location that will not change, because it will be referenced in AutoCad (i.e. the landowners Design Data folder on the shared drive, DO NOT save in the Toolkit folder!)

	FID	Shape '	Easting	Horthing	Elevation	~	
	3154	Point ZM	1682114.88	684687.96	752.3		
	31549	Point ZM	1682116.1	684680.21	752.52		
		Point ZM	1682117.33	684672.39	752.8		-
		Point ZM	1682118.55	684664.58	752.95		
		Point ZM	1682119.78	684656.79	753.15	8	-
		Point ZM	1682121	684648.99	753.1		
		Point ZM	1682122.21	684641_26	753.43		
		Point ZM	1682121.11	684628.01	753.97		
		Point ZM Point ZM	1682119.88 1682118.64	684635.74 684643.54	753.56		
	19199/	POIL 2M	1002110.04		753.38		
port Data				? ×	753.3		
					752.9		
sport: Selected record	55				752.77		
se the same coordinate sy	intern ar				752.6		
	result Q2.				752.39		
This lever's source data					752.53		
7 the data trans					752.64		
The feature dataset you					Saving Data		
			n a geodalabas	0	-	l Desktop 💽 🕒 🗮 🎹	
<ul> <li>the feature dataset you (only applies if you expo</li> </ul>		fure distaset r		0	Look in:		
<ul> <li>the feature dataset you (only applies if you expo lutput table;</li> </ul>		fure distaset r		0	Look in:	REPORTS	
<ul> <li>the feature dataset you (only applies if you expo lutput table;</li> </ul>		fure distaset r		0	Look in:	REPORTS	
<ul> <li>the feature dataset you (only applies if you expo lutput table;</li> </ul>		fure distaset r		0	Look in:	REPORTS	_
<ul> <li>the feature dataset you (only applies if you expo lutput table;</li> </ul>		fure distaset r		0	Look in:	REPORTS	_
<ul> <li>the feature dataset you (only applies if you expo lutput table;</li> </ul>		fure distance in la crowe\Desi	ktop\Export_O	Real (B)	Look in:	REPORTS	
<ul> <li>the feature dataset you (only applies if you expo lutput table;</li> </ul>		fure distaset r	ktop\Export_O	0	Look in:	REPORTS	
<ul> <li>the feature dataset you (only applies if you expo lutput table;</li> </ul>	n to a fea gs\amand	fure distance in la crowe\Desi	ktop\Export_O	Real (B)	Look in:	REPORTS	
<ul> <li>the feature dataset you (only applies if you expo lutput table;</li> </ul>	of to a fea gs\amand 31647	fure distance in	ktop\Export_O	Aput (B)	Look in:	REPORTS	
<ul> <li>the feature dataset you (only applies if you expo lutput table;</li> </ul>	at to a fea	Ia crowe\Desi la crowe\Desi Point ZM Point ZM	K 1682118.22 1682120.61	Apul (2010) Cancel 684578 32 684570.66 684562 39	Look in:	REPORTS	_
<ul> <li>the feature dataset you (only applies if you expo lutput table;</li> </ul>	at to a fee gs\emand 31647 31648 31649 31650	la crowe\Desi la crowe\Desi Point ZM Point ZM Point ZM	K 1682118.22 1682119.42 1682120.61 1682121.82	Cancel 684578.32 684570.66 684562.99 684555.26	Look in:	REPORTS	
<ul> <li>the feature dataset you (only applies if you expo lutput table;</li> </ul>	at to a fee gs\emand 31647 31648 31649 31650	Ia crowe\Desi la crowe\Desi Point ZM Point ZM	K 1682118.22 1682120.61	Apul (201) Cancel 684578 32 684570.66 684562 39	Look in:	_REPORTS [put.cov	88
<ul> <li>the feature dataset you (only applies if you expo lutput table;</li> </ul>	31647 31648 31649 31650 31651	la crowe'Desi la crowe'Desi Point ZM Point ZM Point ZM Point ZM	K 1682118.22 1682121.9.42 1682121.9.42 1682121.82 1682121.79	Aput (2016) Cancel 684578.32 684570.66 684562.99 684555.26 684539.96	Look in:	REPORTS	88
<ul> <li>the feature dataset you (only applies if you expo lutput table;</li> </ul>	31647 31648 31649 31650 31651	la crowe\Desi la crowe\Desi Point ZM Point ZM Point ZM	K 1682118.22 1682119.42 1682120.61 1682121.82	Aput (2016) Cancel 684578.32 684570.66 684562.99 684555.26 684539.96	Look in ECP EQIP_TRP Export_OU	_REPORTS [put.cov	*
<ul> <li>the feature dataset you (only applies if you expo lutput table;</li> </ul>	31647 31648 31649 31650 31651	la crowe'Desi la crowe'Desi Point ZM Point ZM Point ZM Point ZM	K 1682118.22 1682121.9.42 1682121.9.42 1682121.82 1682121.79	Aput (2016) Cancel 684578.32 684570.66 684562.99 684555.26 684539.96	Look in:	PEPORTS put.cv  Project%bit Sav  TestFile Conc  File and Percentil Geoddabase tables	*
<ul> <li>the feature dataset you (only applies if you expo lutput table;</li> </ul>	31647 31648 31649 31650 31651	la crowe'Desi la crowe'Desi Point ZM Point ZM Point ZM Point ZM	K 1682118.22 1682121.9.42 1682121.9.42 1682121.82 1682121.79	Aput (2016) Cancel 684578.32 684570.66 684562.99 684555.26 684539.96	Look in:	PEPORTS put.cov	e

• Click OK on the Export Data window. This will then export the selected records into a new TXT file.

### We are now done using ArcMap

- Open the text file you just created (that contains only our project area data).
- You will need to delete the first row
  - o Delete the text ("FID\_","Easting","Northing","Elevation") and the "blank row"
- Save the file.



## Now open AutoCad Civil 3D

Start with a new project with your appropriate template open.

- Toolspace > Prospector > Right Click on Surfaces > Create Surface (change any settings you want in the dialog box) > OK.
- +EG (or your new surface name) + Definition
- Right Click on "Point FILES" > Add

Check to see if "LaCrosse\_Lidar" is a Point File Format. If it is not listed you will need to create this format. This is a "one time deal," *if you save the changes in your template*. We will create a Point File Format, so that inserting Lidar data on a regular basis will be easy!

- Click on the "Add Point File Format" Icon
- Click "New" in the dialog box
- Select "Use Point File"
- Click "OK"

Avanced options     Avanced options     Stes     Sets     Sets     Sets     Subassentities     Subassen	tive Drawing View	Prospector		
Point Groups Suffaces EG Maksis Boundaries Definition Boundaries Definition Contours Contours Contours Contours Contours Point Groups Point Group	Project X	Pros		
Image: Set				
Masks Watersheds Definition Boundaries Breakines Contours DEN Files Derawing Objects File: Advanced options Controls Surce File: Point File Formats Advanced options Controls Subassembles Subassembles Subassembles Subassembles Cordinate data expansion if possible Do coordinate data expansion if possible Cordinate data expansion if possible Cordinate data expansion if possible Do coordinate data expansion if possible Cordinate data expansion if possible	😑 🍻 Surfaces			
Watersheds     Watersheds     Definition     Boundaries     Breakines     Definition     De				
Definition     Boundaries     B		Add Point File	X	
Breakines     Contours	- Se Watersheds	ê rand		
Breakines     Contours	Boundaries	Tormat:		
Corrand Gonzale Control of C		Hocouest, opiciauaue rive		
Crawing Objects     Face     Force     Fo		Source File:		
Point File Formats     Point File Formats     Advanced options     Advanced options     Do elevation adjustment if possible     Do elevation adjustment if possible     Do coordinate transformation if possible     Do coordinate data expansion			<u> </u>	
	Fole.     Fole.     Fole.     Fold Fles.     Point Fles.     Point Fles.     Point Groups     Point Groups     Point Groups     Point Groups     Stes     Stes     Stes     Subassenbles     Subassenbles     T Survey	Do elevation adjustment if possible Do coordinate transformation if poss Do coordinate data expansion if poss	Autodesk Uploadable File ENZ (comna delmited) ENZ (space delmited) ENZ (comna delmited) PENZ (comna delmited) PENZ (comna delmited) PENZD (space delmited) PENZD (space delmited) PNEZ (space delmited)	New Copy Properties Delete File Formats - Select Format Type
				Close Help

- Give the Format a name (don't use spaces or symbols as part of the name)
- Under "Format Options" Select "Delineated By" and type in a , in the box
- On the boxes at the bottom click on the words <unused> and select the appropriate choice from the list so it matches the picture below. (*notice the first column is unused*)
- Click "OK" Point File Format Type a [, ] here Format options Format name: LaCrosse\_Lidar Columnated Default file extension .: Comment Tag: • Delimited by: .txt × Read no more than points Coordinate zone transform Sample every points Easting Northing Point El... <unused> <unused> <unused> <unused> <unused> <unused> <unuse > Load... Parse OK Cancel Help
  - Choose your new Point File format from the list.
  - Browse to find your "Source file" (the text file with just the project area points)
  - Click "OK"

Format:		
LaCrosse_Lidar	~	
Source File:		
C:\Documents and Se	ettings\amanda.crowe\Desktop\Project_X.txt	F
Advanced options		
Advanced options	uctment if noscible	
Do elevation adj	· · · · · · · · · · · · · · · · · · ·	
Do elevation adj	ustment if possible ansformation if possible ata expansion if possible	

- You may have to type in "ZE" to zoom to your data
- The surface should be automatically created!

